

Communicative damper actuator for adjusting dampers in technical building installations

- Air damper size up to approx. 4 m²
- Torque motor 20 Nm
- Nominal voltage AC/DC 24 V
- Control modulating, communicative 2...10 V variable
- Position feedback 2...10 V variable
- · with connecting terminals
- Conversion of sensor signals
- · Communication via Belimo MP-Bus





RETRO FIT

Technical data			
	Electrical data	Nominal voltage	AC/DC 24 V
	Licotifical data	Nominal voltage frequency	50/60 Hz
		Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V
		Power consumption in operation	3.5 W
		Power consumption in rest position	1.4 W
		Power consumption for wire sizing	6 VA
		Connection supply / control	Terminals 4 mm² (cable Ø410 mm, 4-wire)
		Parallel operation	Yes (note the performance data)
	Franctional data	·	,
	Functional data	Torque motor	20 Nm
		Torque variable	25%, 50%, 75% reduced
		Communicative control	MP-Bus
		Operating range Y	210 V
		Input Impedance	100 kΩ
		Options positioning signal	Open/close
			3-point (AC only)
			Modulating (DC 032 V)
		Operating range Y variable	Start point 0.530 V
		- · · · · · · · · · · · · · · · · · · ·	End point 2.532 V
		Position feedback U	210 V
		Position feedback U note	Max. 0.5 mA
		Position feedback U variable	Start point 0.58 V
		=	End point 2.510 V
		Position accuracy	±5%
		Direction of motion motor	selectable with switch 0/1
		Direction of motion note	Y = 0 V: At switch position 0 (ccw rotation) / 1 (cw rotation)
		Direction of motion variable	electronically reversible
		Manual override	with push-button, can be locked
		Angle of rotation	Max. 95°
		Angle of rotation note	can be limited on both sides with adjustable
			mechanical end stops
		Running time motor	150 s / 90°
		Running time motor variable	86346 s
		Adaptation setting range	manual
		Adaptation setting range variable	No action
			Adaptation when switched on
			Adaptation after pushing the gear
			disengagement button
		Override control	MAX (maximum position) = 100%
			MIN (minimum position) = 0%
		Overwide control veriable	ZS (intermediate position, AC only) = 50%
		Override control variable	MAX = (MIN + 32%)100%
			MIN = 0%(MAX - 32%)
		Cound newer level mater	ZS = MINMAX
		Sound power level, motor	45 dB(A)
		Mechanical interface	Universal shaft clamp reversible 1020 mm
		Position indication	Mechanically, pluggable
	Safety	Protection class IEC/EN	III Safety Extra-Low Voltage (SELV)
		Davids of a state of the	LII Oleve O O vel

UL Class 2 Supply

Protection class UL

Rotary actuator, modulating, communicative, AC/DC 24 V, 20 Nm, Communication via Belimo MP-Bus



Technical data

^ -		

Degree of protection IEC/EN	IP54
Degree of protection NEMA/UL	NEMA 2
Enclosure	UL Enclosure Type 2
EMC	CE according to 2014/30/EU
Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14
Certification UL	cULus according to UL60730-1A, UL60730-2- 14 and CAN/CSA E60730-1:02
Certification UL note	The UL marking on the actuator depends on the production site, the device is UL-compliant in
Made of execution	any case
Mode of operation	Type 1
Mode of operation Rated impulse voltage supply / control	
	Type 1
Rated impulse voltage supply / control	Type 1 0.8 kV
Rated impulse voltage supply / control Control pollution degree	Type 1 0.8 kV 3
Rated impulse voltage supply / control Control pollution degree Ambient temperature	Type 1 0.8 kV 3 -3050°C
Rated impulse voltage supply / control Control pollution degree Ambient temperature Storage temperature	Type 1 0.8 kV 3 -3050°C -4080°C

Safety notes



Weight

- The device must not be used outside the specified field of application, especially not in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation
 or aggressive gases interfere directly with the actuator and that is ensured that the
 ambient conditions remain at any time within the thresholds according to the data
 sheet.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- To calculate the torque required, the specifications supplied by the damper manufacturers concerning the cross-section, the design, the installation site and the ventilation conditions must be observed.
- The device contains electrical and electronic components and must not be disposed
 of as household refuse. All locally valid regulations and requirements must be
 observed.

Product features

Mode of operation

Conventional operation:

The actuator is connected with a standard modulating signal of 0...10 V and drives to the position defined by the positioning signal. The measuring voltage U serves for the electrical display of the actuator position 0.5...100% and as slave control signal for other actuators.

Operation on Bus:

The actuator receives its digital positioning signal from the higher level controller via the MP-Bus and drives to the position defined. Connection U serves as communication interface and does not supply an analogue measuring voltage.

Converter for sensors

Connection option for a sensor (passive or active sensor or switching contact). The MP actuator serves as an analogue/digital converter for the transmission of the sensor signal via MP-Bus to the higher level system.

Parametrisable actuators

The factory settings cover the most common applications. Single parameters can be modified with the Belimo Service Tools MFT-P or ZTH EU.

Simple direct mounting

Simple direct mounting on the damper shaft with a universal shaft clamp, supplied with an anti-rotation device to prevent the actuator from rotating.

Manual override

Manual override with push-button possible (the gear is disengaged for as long as the button is pressed or remains locked).

Adjustable angle of rotation

Adjustable angle of rotation with mechanical end stops.



Product features


High functional reliability

The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.

Home position

The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out a synchronisation. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the positioning signal.



Adaption and synchronisation

An adaption can be triggered manually by pressing the "Adaption" button or with the PC-Tool. Both mechanical end stops are detected during the adaption (entire setting range).

Automatic synchronisation after pressing the gearbox disengagement button is configured. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the positioning signal.

A range of settings can be adapted using the PC-Tool (see MFT-P documentation)

Accessories

	Description	Туре
Gateways	Gateway MP to Modbus RTU	UK24MOD
	Gateway MP zu BACnet MS/TP	UK24BAC
	Gateway MP to LonWorks	UK24LON
	Gateway MP to KNX	UK24EIB
	Description	Туре
Electrical accessories	Auxiliary switch 1 x SPDT add-on	S1A
	Auxiliary switch 2 x SPDT add-on	S2A
	Feedback potentiometer 140 Ω add-on	P140A
	Feedback potentiometer 140 Ω add-on, grau	P140A GR
	Feedback potentiometer 200 Ω add-on	P200A
	Feedback potentiometer 500 Ω add-on	P500A
	Feedback potentiometer 500 Ω add-on, grau	P500A GR
	Feedback potentiometer 1 kΩ add-on	P1000A
	Feedback potentiometer 1 kΩ add-on, grau	P1000A GR
	Feedback potentiometer 2.8 kΩ add-on	P2800A
	Feedback potentiometer 2.8 kΩ add-on, grau	P2800A GR
	Feedback potentiometer 5 k Ω add-on	P5000A
	Feedback potentiometer 5 kΩ add-on, grau	P5000A GR
	Feedback potentiometer 10 kΩ add-on	P10000A
	Feedback potentiometer 10 kΩ add-on, grau	P10000A GR
	Signal converter voltage/current 100 kΩ Supply AC/DC 24 V	Z-UIC
	Range controller for wall mounting	SBG24
	Positioner for wall mounting	SGA24
	Positioner for built-in mounting	SGE24
	Positioner for front-panel mounting	SGF24
	Positioner for wall mounting	CRP24-B1
	Connection cable 5 m, A: RJ11 6/4 ZTH EU, B: 6-pin service socket for Belimo device	ZK1-GEN
	Connection cable 5 m, A: RJ11 6/4 ZTH EU, B: free wire end for connection to MP/PP terminal	ZK2-GEN
	Connecting board MP-Bus for wiring boxes EXT-WR-FPMP	ZFP2-MP
	MP-Bus power supply for MP actuators	ZN230-24MP
	Description	Туре
Mechanical accessories	Actuator arm for standard shaft clamp (reversible)	AH-20
	Shaft extension 240 mm Ø20 mm for damper shaft Ø 1221 mm CrNi	AV12-25-I
	Shaft extension 240 mm Ø20 mm for damper shaft Ø 822.7 mm	AV8-25

Rotary actuator, modulating, communicative, AC/DC 24 V, 20 Nm, Communication via Belimo MP-Bus



Accessories

	Description	Туре
	Ball joint suitable for damper crank arm KH8	KG8
	Ball joint suitable for damper crank arm KH8 / KH10	KG10A
	Damper crank arm Slot width 8.2 mm, clamping range Ø1018 mm	KH8
	Shaft clamp one-sided, clamping range Ø826 mm, Multipack 20 pcs.	K-ENSA
	Shaft clamp one-sided, clamping range Ø1226 mm, for CrNi shaft (INOX), Multipack 20 pcs.	K-ENSA-I
	Shaft clamp reversible, clamping range Ø1020 mm	K-SA
	Anti-rotation mechanism 180 mm, Multipack 20 pcs.	Z-ARS180
	Anti-rotation mechanism 230 mm, Multipack 20 pcs.	Z-ARS230
	Form fit insert 10x10 mm, Multipack 20 pcs.	ZF10-NSA
	Form fit insert 12x12 mm, Multipack 20 pcs.	ZF12-NSA
	Form fit insert 15x15 mm, Multipack 20 pcs.	ZF15-NSA
	Form fit insert 16x16 mm, Multipack 20 pcs.	ZF16-NSA
	Mounting kit for linkage operation for flat installation	ZG-SMA
	Position indicator, Multipack 20 pcs.	Z-PI
	Base plate extension for SMA to SM/AM/SMD24R, Multipack 20 pcs.	Z-SMA
	Terminal protection IP54, Multipack 20 pcs.	Z-TP
	Description	Туре
ervice Tools	Service Tool, with ZIP-USB function	ZTH EU
	Belimo PC-Tool, Software for adjustments and diagnostics	MFT-P
	Adapter for Service-Tool ZTH	MFT-C

Electrical installation



Notes


- Connection via safety isolating transformer.
- Parallel connection of other actuators possible. Observe the performance data.


Wiring diagrams

AC/DC 24 V, modulating

ing










Functions


Functions when operated on MP-Bus

Connection on the MP-Bus



A) more actuators and sensors


(max.8)



A) more actuators and sensors (max.8)

- Supply AC/DC 24 V
- Output signal DC 0...10 V (max. DC 0...32 V)
- Resolution 30 mV


MP-Bus Network topology



There are no restrictions for the network topology (star, ring, tree or mixed forms are permitted). Supply and communication in one and the same 3-wire cable

- · no shielding or twisting necessary
- no terminating resistors required


Connection of external switching contact



A) more actuators and sensors (max.8)

- Switching current 16 mA @ 24 V
- Start point of the operating range must be parameterised on the MP actuator as ≥ 0.5 V

Connection of passive sensors




Ni1000	–28+98°C	8501600 $\Omega^{(2)}$
PT1000	−35+155°C	8501600 Ω ²⁾
NTC	-10+160°C ¹⁾	200 Ω60 kΩ ²⁾


- A) more actuators and sensors (max.8)
- 1) Depending on the type
- 2) Resolution 1 Ohm

Functions with basic values (conventional mode)

Override control with AC 24 V with relay contacts




Override control with AC 24 V with rotary switch







Functions


Control remotely 0...100% with Minimum limit with positioner SG.. positioner SG..







Follow-up control (position-dependent)




Control with 4...20 mA via external resistor 500 Ω ◀ 4...20 mA U → DC 2...10 V ī ī 2 3

Caution:

The operating range must be set to DC 2...10 V.

The 500 Ω resistor converts the 4...20 mA current signal to a voltage signal DC 2...10 V

Functional check




Procedure


- 1. Connect 24V to connections 1 and 2
- 2. Disconnect connection 3:
- with direction of rotation 0:
- Actuator rotates to the left
- with direction of rotation 1:
- Actuator rotates to the right
- 3. Short-circuit connections 2 and 3:
- Actuator runs in opposite direction

Functions for devices with specific parameters (Parametrisation necessary)

Override control and limiting with AC 24 V with relay contacts



Override control and limiting with AC 24 V with rotary switch




1) Caution: This function is only guaranteed if the start point of the operating range is defined as min. 0.5 V.




Functions


Control open/close

Control 3-point





Operating controls and indicators



1 Direction of rotation switch

Switch over: Direction of rotation changes

2 Push-button and LED display green

Off: No power supply or malfuntion

On: In operation

Press button: Triggers angle of rotation adaptation, followed by standard mode

3 Push-button and LED display yellow

Off: Standard mode

Flickering: MP communication active

On: Adaptation or synchronising process active Flashing: Request for addressing from MP master Press button: Confirmation of the addressing

4 Gear disengagement button

Press button: Gear disengages, motor stops, manual override possible

Release button: Gear engages, synchronisation starts, followed by standard mode

5 Service plug

For connecting parameterisation and service tools

Check power supply connection


2 Off and 3 On Possible wiring error in power supply

Service

Service Tools connection

The actuator can be parametrised by ZTH EU via the service socket. For an extended parametrisation the PC tool can be connected.


Connection ZTH EU / PC-Tool





Dimensions [mm]

Spindle length




Clamping range

	<u>OI</u>	_	♦ I
	1020	≥10	≤20
CrNi (INOX)	1220	≥10	≤20

When using a round spindle made of CrNi (INOX): \varnothing 12...20 mm

Dimensional drawings



Further documentation

- Overview MP Cooperation Partners
- · Tool connections
- Introduction to MP-Bus Technology