

Configurable damper actuator for adjusting dampers in technical building installations

- Air damper size up to approx. 4 m<sup>2</sup>
- Torque motor 20 Nm
- Nominal voltage AC/DC 24 V
  Control modulating 0...20 V PhC
- Position feedback 2...10 V





| Гесhnical data  |                                    |  |
|-----------------|------------------------------------|--|
| Electrical data | Nominal voltage                    | AC/DC 24 V                                     |
|                 | Nominal voltage frequency          | 50/60 Hz                                       |
|                 | Nominal voltage range              | AC 19.228.8 V / DC 21.628.8 V                  |
|                 | Power consumption in operation     | 3.5 W  |
|                 | Power consumption in rest position | 1.25 W   |
|                 | Power consumption for wire sizing  | 6 VA   |
|                 | Connection supply / control        | Cable 1 m, 4 x 0.75 mm <sup>2</sup>            |
|                 | Parallel operation                 | Yes (note the performance data)                |
| Functional data | Torque motor                       | 20 Nm  |
|                 | Torque variable                    | 25%, 50%, 75% reduced                          |
|                 | Operating range Y                  | 020 V PhC                                      |
|                 | Input Impedance                    | 8.2 kΩ   |
|                 | Position feedback U                | 210 V  |
|                 | Position feedback U note           | Max. 0.5 mA                                    |
|                 | Position feedback U variable       | Start point 0.58 V                             |
|                 |                                    | End point 2.510 V                              |
|                 | Position accuracy                  | ±5%  |
|                 | Direction of motion motor          | selectable with switch 0/1                     |
|                 | Direction of motion note           | Y = 0 V: At switch position 0 (ccw rotation) / |
|                 |                                    | 1 (cw rotation)                                |
|                 | Direction of motion variable       | electronically reversible                      |
|                 | Manual override                    | with push-button, can be locked                |
|                 | Angle of rotation                  | Max. 95°                                       |
|                 | Angle of rotation note             | can be limited on both sides with adjustable   |
|                 |                                    | mechanical end stops                           |
|                 | Running time motor                 | 150 s / 90°                                    |
|                 | Running time motor variable        | 90350 s  |
|                 | Adaptation setting range           | manual   |
|                 | Adaptation setting range variable  | No action                                      |
|                 |                                    | Adaptation when switched on                    |
|                 |                                    | Adaptation after pushing the gear              |
|                 |                                    | disengagement button                           |
|                 | Override control                   | MAX (maximum position) = 100%                  |
|                 | 0                                  | MIN (minimum position) = 0%                    |
|                 | Override control variable          | MAX = (MIN + 32%)100%                          |
|                 | Cound naviou lovel mater           | MIN = 0%(MAX - 32%)                            |
|                 | Sound power level, motor           | 45 dB(A)                                       |
|                 | Mechanical interface               | Universal shaft clamp reversible 1020 mm       |
|                 | Position indication                | Mechanically, pluggable                        |
| Safety          | Protection class IEC/EN            | III Safety Extra-Low Voltage (SELV)            |
|                 | Protection class UL                | UL Class 2 Supply                              |
|                 | Degree of protection IEC/EN        | IP54   |
|                 | Degree of protection NEMA/UL       | NEMA 2   |
|                 | Enclosure                          | UL Enclosure Type 2                            |
|                 | EMC                                | CE according to 2014/30/EU                     |
|                 | Certification IEC/EN               | IEC/EN 60730-1 and IEC/EN 60730-2-14           |
|                 | Certification UL                   | cULus according to UL60730-1A, UL60730-2       |

14 and CAN/CSA E60730-1:02



| Technical data |        |  |   |
|----------------|--------|--|---|
|                | Safety | Certification UL note                  | The UL marking on the actuator depends on the production site, the device is UL-compliant in any case |
|                |        | Mode of operation                      | Type 1  |
|                |        | Rated impulse voltage supply / control | 0.8 kV  |
|                |        | Control pollution degree               | 3   |
|                |        | Ambient temperature                    | -3050°C   |
|                |        | Storage temperature                    | -4080°C   |
|                |        | Ambient humidity                       | Max. 95% r.H., non-condensing   |
|                |        | Servicing                              | maintenance-free  |
| ν              | Neight | Weight                                 | 1.9 kg  |

#### Safety notes



· The device must not be used outside the specified field of application, especially not in aircraft or in any other airborne means of transport.

- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the actuator and that is ensured that the ambient conditions remain at any time within the thresholds according to the data sheet.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- Cables must not be removed from the device.
- To calculate the torque required, the specifications supplied by the damper manufacturers concerning the cross-section, the design, the installation site and the ventilation conditions must be observed.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

#### **Product features**

Mode of operation

The actuator is connected with a standard modulating signal of 0...20 V phase-cut signal and drives to the position defined by the positioning signal.

Measuring voltage U serves for the electrical display of the damper position 0...100% and as slave control signal for other actuators.

Parametrisable actuators

The factory settings cover the most common applications. Single parameters can be modified with the Belimo Service Tools MFT-P or ZTH EU.

Simple direct mounting

Simple direct mounting on the damper shaft with a universal shaft clamp, supplied with an anti-rotation device to prevent the actuator from rotating.

Manual override

Manual override with push-button possible (the gear is disengaged for as long as the button is pressed or remains locked).

Adjustable angle of rotation

Adjustable angle of rotation with mechanical end stops.


High functional reliability

The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.

Home position

The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out a synchronisation. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the positioning signal.





# **Product features**

#### Adaption and synchronisation

An adaption can be triggered manually by pressing the "Adaption" button or with the PC-Tool. Both mechanical end stops are detected during the adaption (entire setting range).

Automatic synchronisation after pressing the gearbox disengagement button is configured. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the positioning signal. A range of settings can be adapted using the PC-Tool (see MFT-P documentation)

#### **Accessories**

|                        | Description   | Туре       |
|------------------------|---|------------|
| Electrical accessories | Auxiliary switch 1 x SPDT add-on  | S1A        |
|                        | Auxiliary switch 2 x SPDT add-on  | S2A        |
|                        | Auxiliary switch 2 x SPDT add-on, grau  | S2A/300 GR |
|                        | Auxiliary switch 2 x SPDT add-on, grau  | S2A/500 GR |
|                        | Feedback potentiometer 200 $\Omega$ add-on  | P200A      |
|                        | Feedback potentiometer 500 $\Omega$ add-on  | P500A      |
|                        | Feedback potentiometer 500 $\Omega$ add-on, grau  | P500A GR   |
|                        | Feedback potentiometer 1 kΩ add-on  | P1000A     |
|                        | Feedback potentiometer 2.8 kΩ add-on  | P2800A     |
|                        | Feedback potentiometer 2.8 kΩ add-on, grau  | P2800A GR  |
|                        | Feedback potentiometer 1 kΩ add-on, grau  | P1000A GR  |
|                        | Feedback potentiometer 5 k $\Omega$ add-on  | P5000A     |
|                        | Feedback potentiometer 5 kΩ add-on, grau  | P5000A GR  |
|                        | Feedback potentiometer 10 k $\Omega$ add-on   | P10000A    |
|                        | Feedback potentiometer 10 k $\Omega$ add-on, grau   | P10000A GR |
|                        | Signal converter voltage/current 100 kΩ Supply AC/DC 24 V                                   | Z-UIC      |
|                        | Range controller for wall mounting  | SBG24      |
|                        | Positioner for wall mounting  | SGA24      |
|                        | Positioner for built-in mounting  | SGE24      |
|                        | Positioner for front-panel mounting   | SGF24      |
|                        | Positioner for wall mounting  | CRP24-B1   |
|                        | Connection cable 5 m, A: RJ11 6/4 ZTH EU, B: 6-pin service socket for Belimo device         | ZK1-GEN    |
|                        | Connection cable 5 m, A: RJ11 6/4 ZTH EU, B: free wire end for connection to MP/PP terminal | ZK2-GEN    |
|                        | Description   | Туре       |
| Mechanical accessories | Actuator arm for standard shaft clamp (reversible)  | AH-20      |
|                        | Shaft extension 240 mm Ø20 mm for damper shaft Ø 1221 mm CrNi                               | AV12-25-I  |
|                        | Shaft extension 240 mm Ø20 mm for damper shaft Ø 822.7 mm                                   | AV8-25     |
|                        | Ball joint suitable for damper crank arm KH8  | KG8        |
|                        | Ball joint suitable for damper crank arm KH8 / KH10   | KG10A      |
|                        | Damper crank arm Slot width 8.2 mm, clamping range Ø1018 mm                                 | KH8        |
|                        | Shaft clamp one-sided, clamping range Ø826 mm, Multipack 20 pcs.                            | K-ENSA     |
|                        | Shaft clamp one-sided, clamping range Ø1226 mm, for CrNi shaft (INOX), Multipack 20 pcs.    | K-ENSA-I   |
|                        | Shaft clamp reversible, clamping range Ø1020 mm   | K-SA       |
|                        | Anti-rotation mechanism 180 mm, Multipack 20 pcs.   | Z-ARS180   |
|                        | Anti-rotation mechanism 230 mm, Multipack 20 pcs.   | Z-ARS230   |
|                        | Form fit insert 10x10 mm, Multipack 20 pcs.   | ZF10-NSA   |
|                        | Form fit insert 12x12 mm, Multipack 20 pcs.   | ZF12-NSA   |
|                        | Form fit insert 15x15 mm, Multipack 20 pcs.   | ZF15-NSA   |
|                        | Form fit insert 16x16 mm, Multipack 20 pcs.   | ZF16-NSA   |
|                        | Mounting kit for linkage operation for flat installation                                    | ZG-SMA     |
|                        | Position indicator, Multipack 20 pcs.   | Z-PI       |
|                        |   |            |

Base plate extension for SM..A to SM../AM../SMD24R, Multipack 20

Z-SMA



# **Accessories**

|               | Description  | Туре   |
|---------------|--|--------|
| Service Tools | Service Tool, with ZIP-USB function                      | ZTH EU |
|               | Adapter for Service-Tool ZTH                             | MFT-C  |
|               | Belimo PC-Tool, Software for adjustments and diagnostics | MFT-P  |

# **Electrical installation**




**Notes** 

- · Connection via safety isolating transformer.
- Parallel connection of other actuators possible. Observe the performance data.

#### Wiring diagrams

AC/DC 24 V, modulating



#### Cable colours:

1 = black

2 = red


5 = orange

6 = pink


# **Functions**

# Functions with basic values (conventional mode)

Override control with AC 24 V with relay contacts



#### Master/Slave control




Override control with AC 24 V with rotary control switch

Pos | 1 0%

2


3 Y

100%





# Operating controls and indicators



1 Direction of rotation switch

Switch over: Direction of rotation changes

2 Push-button and LED display green

Off: No power supply or malfuntion

On: In operation

Press button: Triggers angle of rotation adaptation, followed by standard mode

3 Push-button and LED display yellow

Off: Standard mode

On: Adaptation or synchronising process active

Press button: No function

4 Gear disengagement button

Press button: Gear disengages, motor stops, manual override possible

Release button: Gear engages, synchronisation starts, followed by standard mode

5 Service plug

For connecting parameterisation and service tools


# Check power supply connection

2 Off and 3 On Possible wiring error in power supply

#### **Service**


#### **Service Tools connection**

The actuator can be configured by PC-Tool and ZTH EU via the service socket. Connection ZTH EU / PC-Tool



#### Dimensions [mm]

### Spindle length



### Clamping range

|             | <u>OI</u> | <b>□</b> <u></u> | $\Diamond$ |
|-------------|-----------|------------------|------------|
|             | 1020      | ≥10              | ≤20        |
| CrNi (INOX) | 1220      | ≥10              | ≤20        |

When using a round spindle made of CrNi (INOX):  $\emptyset$  12...20 mm

### **Dimensional drawings**

